

REACT TAKEOFF CHECKLIST

- 1 RPM'S = 2330 - 2430
- 2 ENGINE GAUGES = GREEN
- 3 AIRSPEED = "ALIVE"
- 4 CENTERLINE
- 5 TAKEOFF ABORT POINT (DECISION POINT)

Once the decision is made to abort a takeoff, immediately reduce the power to IDLE while maintaining directional control using the rudder and aileron into a crosswind to stop the drift.

